
TrueNAS® Mini E+ Network Port IDs

v.23111




Contents

1	Introduction	1
2	Mini E+ (16G and 32G RAM)	2
3	Additional Resources	2
4	Contacting iXsystems	2

1 Introduction

TrueNAS SCALE enumerates interface names using PCI locations. By default, SCALE systems identify their network ports with **eno** or **enp** followed by a number.



The tables below show the default SCALE identification for Mini systems and any add-on networking cards qualified by iXsystems for use with Mini systems.

2 Mini E+ (16G and 32G RAM)

NIC	Port 0 ID	Port 1 ID	Port 2 ID	Port 3 ID
Integrated	enp4s0f0	enp4s0f1	enp6s0f0	enp6s0f1

3 Additional Resources

The TrueNAS Documentation Hub has complete software configuration and usage instructions. Click **Guide** in the TrueNAS web interface or go directly to:

https://www.truenas.com/docs

Additional hardware guides and articles are in the Documentation Hub's Hardware section:

https://www.truenas.com/docs/hardware

The TrueNAS Community forums provide opportunities to interact with other TrueNAS users and discuss their configurations:

https://www.truenas.com/community

4 Contacting iXsystems

Having issues? Please contact iX Support to ensure a smooth resolution.

Contact Method	Contact Options
Web	https://support.ixsystems.com
Email	support@iXsystems.com
Telephone	Monday-Friday, 6:00AM to 6:00PM Pacific Standard Time: • US-only toll-free: 1-855-473-7449 option 2 • Local and international: 1-408-943-4100 option 2
Telephone	Telephone After Hours (24x7 Gold Level Support only): • US-only toll-free: 1-855-499-5131 • International: 1-408-878-3140 (International calling rates will apply)

Page 1 v. 23111