TrueNAS[®] Mini Network Port IDs

v.25011



Contents

1	Introduction	1
3	Mini X+ and Mini R (32G and 64G RAM)	1
4	Additional Resources	1
5	Contacting iXsystems	1

Copyright © 2024 iXsystems, Inc. All rights reserved. All trademarks are the property of their respective owners.

1 Introduction

TrueNAS SCALE enumerates interface names using PCI locations. By default, SCALE systems identify their network ports with **eno** or **enp** followed by a number.

Interfaces		Add
Name	IP Addresses	
enp2s0f0		Ī
enp2s0f1		ī
1 eno1	• 10.220.20.160/20	Ī
💃 eno2		Ī

The table below show the default SCALE identification for Mini systems and any add-on networking cards qualified by iXsystems for use with Mini systems.

3 Mini X+ and Mini R (32G and 64G RAM)

NIC	Port 0 ID	Port 1 ID
Integrated	eno1	eno2
SR 40GbE x2	enp2s0f4	enp2s0f4d1

4 Additional Resources

The TrueNAS Documentation Hub has complete software configuration and usage instructions. Click **Guide** in the TrueNAS web interface or go directly to:

https://www.truenas.com/docs

Additional hardware guides and articles are in the Documentation Hub's Hardware section:

https://www.truenas.com/docs/hardware

The TrueNAS Forums provide opportunities to interact with other TrueNAS users and discuss their configurations:

https://forums.truenas.com/

5 Contacting iXsystems

Having issues? Please contact iX Support to ensure a smooth resolution.

Contact Method	Contact Options
Web	https://support.ixsystems.com
Email	support@iXsystems.com
Telephone	Monday-Friday, 6:00AM to 6:00PM Pacific Standard Time: • US-only toll-free: 1-855-473-7449 option 2 • Local and international: 1-408-943-4100 option 2
Telephone	Telephone After Hours (24x7 Gold Level Support only): • US-only toll-free: 1-855-499-5131 • International: 1-408-878-3140 (International calling rates will apply)